

NOTE

OC3 IS NOT AVAILABLE WHEN USING THE CHARGE PUMP FUNCTION

CHARGE PUMP FREQUENCY = 1.2MHZ DIVIDED BY THE VALUE OF PARAMETER 960

A VALUE OF 0 IN PARAMETER 960 DISABLES THE CHARGE PUMP FUNCTION.

E-STOP CIRCUITS ARE **RED**

OPTIONAL CONNECTIONS ARE **BLUE**

GROUND S ARE **GREEN**

110VAC IS **VIOLET**

Title ACORN_rev3 TO GECKO G540 WITH STOCK DB25 CONNECTIONS Legacy			
Date	170829	Drawn by	CEM
Filename		Sheet	1 of 1

How to tell the difference between Acorn\_rev2 and Acorn\_rev3

Acorn\_rev2 has FIXED green screw terminal blocks

Acorn\_rev3 has REMOVABLE green screw terminal blocks

NOTE: DO NOT MAKE ANY CONNECTIONS TO THE ACORN BOARD INPUTS 1-5 AS THEY ARE USED BY THE G540 DB25 PASS THRU CABLE.

E-STOP SWITCH  
(NORMALLY CLOSED)

