

TB160 (Rev1) - Running Mastercam with Networking or PLC Executer

Overview

This document tells you what the limitations are of running Mastercam on your control.

Configuration Types:

1. New System (running PLC executer as of software version 8.13)

*These systems can run Mastercam or be setup for networking but can not do both.

2. Uniconsole systems (only systems with PLCIO2)

*These systems also can run Mastercam or networked but not both.

3. All other systems

* These systems do not have the PLC executer therefore they can run Mastercam and be setup for networking. For configuring your control for networking see Tech bulletin 99.

* Note: You will not be able to run 2-way networking if Mastercam is installed and run.

Document History

Rev1 Created on **2002-08-08**