

TB038 (Rev1) - Changing Mouse Sensitivity

Overview

This document describes the steps to take to change the sensitivity, or speed, of the mouse.

Procedure:

1. From the main screen of the control press **CTRL + ALT + X** to exit to DOS. You will see the prompt below. Enter the following lines:

- **C:\CNC7>cd**
- **C:\>edit autoexec.bat**

2. Now you will be in a text editor. Use the arrow keys or other text navigation keys to find the line near the end of the file that reads:

- **LH C:\nc\drivers\mouse.com /S10**

3. Change the 10 to a value between 1-100, with one being the slowest and 100 the fastest.

4. Exit the editor - Choose **ALT+F, X**, and then **ENTER** when prompted to save changes.

5. Turn off the control and reboot.

Document History

Rev1 Created on **1998-04-14**